



Buckeye Eco Glass Cleaner HD is dilutable and can be used on glass, windows, mirrors, Plexiglas[®], etc. Buckeye Eco Glass Cleaner HD dries quickly, without streaking, reducing time and labour. It does not contain alcohol, butyl or ammonia, which may be hazardous to employees and could damage surfaces.



This product meets Green Seal[™] Standard GS-37 based on effective performance, concentrated volume, minimized/ recycled packaging, and protective limits on VOCs and human & environmental toxicity. GreenSeal.org.

FEATURES • ADVANTAGES • BENEFITS

FEATURES

- No alcohol, butyl or ammonia
- No residue left behind
- Excellent for windows, mirrors, Plexiglas[®], computer screens, optical scanners, etc.
- Low end-use cost per litre
- Pleasant ocean surf fragrance

ADVANTAGES

- Fast drying
- Efficient cleaning and polishing
- Easy measuring with Eco Squeeze & Pour bottle
- Environmentally responsible

BENEFITS

- Leaves no streaks
- Reduces time and labour
- Less product waste





1:16 makes 21 end-use litres, which is equivalent to:



4 quarts (946 mL/32 oz)

Each 4x1 case makes 90 end-use quarts/84 end-use litres

0.95 L Squeeze & Pour Yield Rate



1:16 makes 16 end-use litres, which is equivalent to:

17 quarts (946 mL/32 oz)

Each 6x1 case makes 102 end-use quarts/96 end-use litres



Directions for Use

Connecting 1.25 L Bags to Eco Unit

- 1. Remove 1.25 L bag from carton.
- 2. To open the Eco unit product compartment, depress the top of the unit with your fingers and pull the compartment down towards you with your other hand.
- 3. Align Eco unit connector cap lugs with 1.25 L bag metering plug channels. Rotate clockwise to lock in place.
- 4. Fit 1.25 L bag neatly into product compartment with hose barb pointed downward.
- *Ensure chemical line is not pinched.
- 5. Close Eco unit product compartment.

Dispensing Diluted Product into 946 mL Trigger Spray Bottle

- 1. Use appropriate 946 mL trigger spray bottle, and slide up over 127 mm discharge hose.
- 2. Push back lever to dispense cold water diluted product.
- 3. Once trigger spray bottle is filled (approximately 51 mm from top), release lever to avoid overfilling.

For trigger spray bottle cleaning:

- 1. Fill a trigger spray bottle and apply to the area to be cleaned.
- 2. Wipe dry with a clean, lint-free cloth or non-treated paper towel. For computer screens, spray on clean, lint-free cloth or non-treated paper towel and apply to screen.

For large area window cleaning:

- 1. Apply from bucket with a window brush or suitable applicator.
- 2. Remove with a squeegee and wipe excess cleaner from blade, window frames and ledges with a clean cloth.

0.95 L Squeeze & Pour Bottles (S12) – User Instructions:

For squeegee/mop bucket applications:

Use 16 oz. per prefilled 2 gallons of cold water

For Eco 32 oz. trigger spray bottle:

Use 2 oz. per prefilled Eco trigger spray bottle of cold water



Available in:



Eco Glass Cleaner HD Technical Specifications	
pH Concentrate	7.5 ± 0.5
pH 8 oz./gal. (1:16)	7.0 ± 0.5
Specific Gravity	1.00 gr/ml
Flash Point	155° F
Colour	Dark Blue
Fragrance	Ocean Surf
Formulated without Ammonia, Amines, Butyl or Alcohols	Yes

Improper use and dilution may result in inadequate cleaning and may result in health and physical hazards that match those of the concentrate. When handling concentrated product, wearing safety glasses and gloves is suggested.

Dispose of unused product and solutions in accordance with local, state, and federal regulations.

For more information about E12/S12, scan this code.





Buckeye International, Inc. 2700 Wagner Place • Maryland Heights • MO 63043 • USA 800.321.2583 • www.buckeyeinternational.com